

INNOVATIVE DESIGNS FOR CREATIVE SPACES

Tools Required for Leg Installation:

- #2 Phillips Head Screwdriver
- (Recommended) Cordless Screwdriver with #2 Phillips Bit

Step 1

Carefully remove outer packaging and place the table topside-down on a clean, non-scratching surface.

You will see four or more heavy duty steel brackets on the underside of the table top. These brackets have been pre-installed at the factory to ensure perfect leg positioning and make assembly easier and faster.



Step 2

Set the heights of your Classic legs. Use a standard #2 Phillips head screwdriver to tighten the pair of set screws. Check that all legs are set to the same height before proceeding.

NOTE: Allow for the table top thickness of 1-1/4" when determining height.

Step 3

Turn the leg upside down and slide it fully into the pre-installed bracket. The pilot hole will be visible when the leg is fully engaged. Install the Phillips head screw through the slotted center hole and into the table top. Tighten fully, and repeat for all remaining legs.

Proceed to Wire Management Panel Assembly.

W-Series 4-Leg Table w/ Wire Management

Assembly Instructions

Hardware Included:

- 4 x 3/4" #10 Phillips Head Screws
- 8 x 3/4" Pan Head Phillips Head Screws (2 per leg)







INNOVATIVE DESIGNS FOR CREATIVE SPACES®

Tools Required for Panel Assembly:

- 8" Phillips Screwdriver or Cordless Screwdriver • with 8" or Longer Extension and #2 Phillips Bit
- 7/16" Socket and 7/16" Combination Wrench

Step 4

Wire Management Panel

Assembly Instructions

Hardware Included:

10 x 3/4" Phillips Wood Screws

4 x 1/4" Hex Bolts 4 x 1/4" Hex Nuts



≪aaaaaaa(5

